



INSTALLATION INSTRUCTIONS FOR NORTHERN CONTOURS SUPPLIED FLOATING SHELF BRACKET

- 1** Determine shelf's location on the wall making sure at least 1 hole in the bracket aligns with a stud, 2 holes for shelves over 40".




- 2** Remove metal bracket from the shelf and place against wall. Holes on the bracket should be on the top edge. Using a level and a pencil, place marks on the wall through the bracket holes that align with studs. Drill pilot holes through wall when using wall anchors


- 3** Secure bracket to the wall with screws (not provided). Prongs should be level or slightly angled up. Slide shelf over bracket.



- 4** Secure shelf to bracket. Hold shelf tight to the wall. Using a 9/64 drill bit, drill a pilot hole through the shelf and metal bracket. Drill 5/8" from the back of the shelf into top or bottom, whichever is less visible once installed. Drill 1 hole in the center for shelves up to 40", 2 holes equally spaced for shelves over 40"



- 5** Install a #8 screw (provided) into shelf and bracket. Shelf should be tight against the wall and ready for styling.



The metal bracket needs to be anchored to the wall properly to support the potential load. We recommend no more than 10 lbs per lineal foot. If you cannot drill into 2 studs, use professional grade toggle bolts or wall anchors with load rating above 50 lbs. Northern Contours is not liable for any damage caused by improper installation.

NORTHERN } CONTOURS®

877-998-1814 | www.northerncontours.com

WATCH OUR VIDEO
TUTORIAL BY SCANNING
OR GOING TO OUR
YOUTUBE PAGE
@NORTHERNCONTOURS

